

Switch Matrix: Pinball Champ

	0	1	2	3	4	5	6	7
0	0 Test Advance	1 Test Return	2 Tilt 2	3 Service Credit	4 Coin Switch 1	5 Coin Switch 2	6 Coin Switch 3	7 <i>Not Used</i>
1	8 <i>Not Used</i>	9 Credit	10 Tilt	11 Factory Burn Test	12 <i>Not Used</i>	13 <i>Not Used</i>	14 <i>Not Used</i>	15 Printer Contact
2	16 Outhole	17 Left Outlane	18 Left Inlane	19 Left Slingshot	20 Right Slingshot	21 Right Inlane	22 Right Outlane	23 Right Outlane Kicker
3	24 Rebound Contact (behind Left Drop Target Bank)	25 Left Drop Target	26 Middle Left Drop Target	27 Middle Right Drop Target	28 Right Drop Target	29 Fixed Special Red Target	30 Fixed Special Orange Target	31 Left Drop Target
4	32 Middle Drop Target	33 Right Drop Target	34 Spinner	35 Left Lane Button #1 (bottom)	36 Left Lane Button #2	37 Left Lane Button #3	38 Left Lane Button #4	39 Left Lane Button #5 (top)
5	40 Upper Playfield: Left Drop Target	41 Upper Playfield: Middle Left Drop Target	42 Upper Playfield: Middle Drop Target	43 Upper Playfield: Middle Right Drop Target	44 Upper Playfield: Right Drop Target	45 Fixed Target #1	46 Fixed Target #2	47 Left Pop Bumper
6	48 Right Pop Bumper	49 Fixed Target #5	50 Fixed Target #4	51 Fixed Target #3	52 Upper Playfield Rollunder	53 <i>Not Used</i>	54 <i>Not Used</i>	55 <i>Not Used</i>
7	56 <i>Not Used</i>	57 <i>Not Used</i>	58 <i>Not Used</i>	59 <i>Not Used</i>	60 <i>Not Used</i>	61 <i>Not Used</i>	62 <i>Not Used</i>	63 <i>Not Used</i>

Information contributed by Cliff "Cliffy" Rinear.

David Gersic info@zaccaria-pinball.com

Copyright © 2001. All rights reserved.

This document may be freely distributed so long as the content is not modified.

Last updated 5 November 2001